



Toolholders for inserts CCGT, CCGW, CCGX, CCMT and CCMW



- For inserts programme, see page(s) 394-398, 452, 480-481
- GAMO° = Rake angle, LAMS° = Inclination angle
- For holder code key, see page(s) 17-18

[illegible]

Spare Parts, Parts included in delivery


For size	Insert key	Insert screw	Coolant adapter
			
A08K-..	T07P-2	C02505-T07P	-
A10L-..	T07P-2	C02505-T07P	-
A12N-..	T07P-2	C02506-T07P	-
A16Q-..	T07P-2	C02506-T07P	SEAL 16

Accessories, to be ordered separately

Coolant adapter	
	
—	
—	
—	
SEAL16	

Please check availability in current price and stock-list

-



For size	Insert key	Insert screw	Coolant adapter
			
A12N-..	T15P-2	C04008-T15P	—
A16Q-..	T15P-2	C04008-T15P	SEAL16
A20R-..	T15P-2	C04008-T15P	SEAL20

327